

# ***Tex Clean Scum Away: A White Scum Remover***

TEX CLEAN SCUM AWAY, a white scum remover, is formulated for the removal of salt scum deposits found on clay brick and tile surfaces. White scum is the formation of hard salt deposits on tile and the face of brick. With TEX CLEAN SCUM AWAY, these deposits can be easily removed. TEX CLEAN SCUM AWAY is a highly corrosive liquid and special precautions must be taken to ensure this product is used only on clay brick and tile. Be sure to avoid any contact with other surfaces as they may be damaged if contact is made with SCUM AWAY. For exceptional results, please read and follow mixing, application, and safety information which is on the label of this product.

## **APPLICATION PRECAUTIONS**

Cover all plants, sidewalks, metals, glass, aluminum (columns, window frames, etc.) and any other non-masonry item that may be damaged by this product. Beware of drifting of sprayed product, fumes or rinse water. Avoid exposing anyone without proper safety equipment to spray, splash, or fumes.

***READ ALL PRECAUTION AND SAFETY INFORMATION BEFORE APPLYING PRODUCT!***

## **APPLICATION**

Always test a small area (4 – 6 Sq. Ft.) and allow it to dry thoroughly to insure the desired result.

Dilute one part TEX CLEAN white scum remover to one part water. Always contain solution in a polyethylene or plastic bucket, and never use in areas that do not provide adequate ventilation. Applicators should wear rubber gloves, goggles, face shields and clothing that prevent cleaner from coming into contact with the skin. Disposable filter respirators must be worn when working in confined area.

Thoroughly pre-wet a large surface area with water and generously apply product using low pressure spray, roller, or masonry washing brush. Allow product to remain on masonry surface for 1-3 minutes before rinsing. When it is time for removal, rinse thoroughly with fresh water, using low water pressure at first and then increasing to a hard stream while lightly scrubbing with a clean fiber brush. Reapply cleaning solution and scrub the surface as required. Caution: Do not allow cleaning solution to “dry-in” to the masonry – bleaching may result.

**Houston**  
2800 N. Gordon St.  
Alvin, TX 77511  
Ph: (281) 331-0088  
Fax: (281) 331-9813  
(800) 873-5794

**Austin**  
1585 Jack C. Hays Trail  
Buda, TX 78610  
Ph: (512) 312-0879  
Fax: (512) 295-3277  
(800) 499-0984

**Dallas**  
400 N Hwy 377  
Roanoke, TX 76262  
Ph: (817) 491-0531  
Fax: (817) 430-4370  
(800) 525-5382